

## Accessories MKS

**Tool group A06**
**Type ELS spare live centres 60° standard design**


Item no.	Size	Weight
005339	02	85
005432	04	90
005472	08	190
005493	10	510
005550	14	1340
005660	100	13
005728	102	150
005780	104	150
005796	108	380
005806	110	710
005896	106	200
005911	114	1330
009192	453 + 503	190
009205	454 + 504	360
009325	455 + 505	760
009413	506	1610
009841	156	150
010175	158	300
012677	160	610
043398	101	45
093458	116	2700
093464	116	3200
301978	426	2580
306182	425	1060
306202	424	460
324478	106	200
338895	705/65	410
338901	705/82 + 706/82	710
344923	704/70	500
344924	704/52	200
344925	706/110	1890

**Tool group A06**
**Type ELS spare live centres 60° carbide-tipped**


Item no.	Size	Weight
032141	102	90
090090	104	160
090214	108	390
090330	106	220
097545	101	60
221033	110	720
221034	114	1330

**Tool group A06**
**Type ELS spare live centres 60° extended live centre**


Item no.	Size	Weight
068722	101	240
068723	102	350
068724	106	400
068725	108	400
068727	110	750
068728	114	1500
079924	453 + 503	200
079925	454 + 504	400
079926	455 + 505	800
079927	506	1700
362085	02	85
362086	04	90
362087	08	190
362088	10	510
362089	14	1340

**Tool group A06**
**Type ELS spare live centres 60° extended NC-centre with carbide insert**


Item no.	Size	Weight
790267	752 + 753	190
790291	754 + 755	760

**Tool group A06**
**Type ELS spare live centres 60° with centre bore**


Item no.	Size	Weight
221267	101	40
221268	102	80
221269	104	140
221270	106	190
221271	108	360
221272	110	700
221273	114	1300